




## Important information


- The flooring must be acclimated a minimum of 24 to 48 hours prior to installation in the room where the installation will take place
- In larger rooms the flooring must be installed in smaller sections with expansion joints.
- The distance to walls and other permanent pieces of construction elements (such as pillars and kitchen islands) should be approximately 5 mm
- Never install very heavy pieces of furniture such as kitchen islands/cabinets on top of the flooring
- The indoor climate should have a temperature between 15-23 ° C and relative air humidity between 30-60%.
- Always follow the floor manufacturers requirements and specifications regarding subfloor preparation.

## General installation instructions




### First row, first plank

Place a spacer with predicted thickness to the left and position the panel against the wall.  
Later, after 3 rows, you can easily position the flooring against the front wall with predicted spacers.




### Second row, first plank.

Start with the rest of the cut plank from the first row.




### First row, second plank


Place this panel gently close to the short end of the first one.



Staggered joint distance i.e. minimum distance between short ends of panels in parallel rows shall not be less than the given length.




When folding down it is important to start from the corner closest to the previous row, folding down towards the center, and continue towards the opposite long side. During the fold down, make sure the panels are close to each other.




### Second row, second plank.

Place the panel gently and close to the short end of the previous panel and fold it down in a single action movement.




Afterwards press slightly along the short end just installed.




### After 2-3 rows.

Adjust the distance to the front wall by placing spacers.





At the end of the first row, put a spacer to the wall and measure the length of the last plank to fit.





*The first and last row may need to be adjusted at an uneven wall. Copy the wall line to the first or last plank row with the shown tool, disassemble planks, adjust and reinstall.*

## Installation around radiator/heating pipes




Drill holes two times larger than the diameter of the pipes. Remove a piece of the panel with a utility knife. Put the panel on one side of the pipes and the removed piece on the other side.




Remove the vertical locking part of the strip with a chisel, put applicable glue on the strip and push the planks horizontally together. Place some spacers between last board and the wall.

## Dismantling panels



Separate the whole row by carefully lifting up and release the whole row. Fold up the row and release the whole long side.



Disassemble the panels by sliding the short ends horizontally. **Never fold up a panel, as this damages the profile.**